HIRARC

- Guidelines for Hazard Identification, Risk Assessment and Risk Control
- Published by Department of Occupational Safety and Health (DOSH) 2008.



Guidelines

for Hazard
Identification,
Risk Assessment
and Risk Control
(HIRARG)

Department of Occupational Safety and Health Ministry of Human Resources Malaysia

2008

JKKP DP 127/789/4-47 ISBN 978-883-2014-62-1

WHAT IS HIRARC?

HAZARD IDENTIFICATION

Identify hazard source or situation



RISK ASSESSMENT

Estimate level of risk and determine tolerability



RISK CONTROL

Reduce or eliminate risk

DOCUMENTING HIRARC




BORANG HIRARC (HIRARC FORM)

Jabatan/Unit/Makmal/Wad/Stor:			Disediakan Oleh: (Nama, Jawatan)			
Proses Kerja/Lokasi:						
Disahkan Oleh:			Tarikh Disediakan:	(dari)	hingga	
(Nama, Jawatan, Tandatangan)			Tarikh Disemak:			
Tarikh Disahkan:			Tarikh Semakan Semula:			
			·			

1. Pengenalpastian Hazard				2. Analisis Ri	siko		3. Kawalan Ri	siko		
	Bil.	Aktiviti Kerja	Hazad	Yang Boleh Mengakibatkan/Kesan	Kawalan Risiko (sedia ada)	Kebarangkalian (A)	Keterukan (B)	Tahap Risiko (AxB)	Disarankan	Orang Bertanggungjawab (Tarikh Tamat/Status)
	1									

a Ameliate piette.

HIRARC FLOWCHART



TYPE OF HAZARDS

PHYSICAL

Slippery floors, electric shock, sharp object, height, fire, radiation, magnetic fields, pressure, noise, etc.



Depends on the physical, chemical and toxic properties of the chemical

BIOLOGICAL

Pathogens, bacteria, viruses, insects, plants, birds, animals, and humans, etc.

ERGONOMIC

Repetitive movements, improper set up of workstation, poor design of equipment, workstation design, (postural) or workflow, manual handling, etc.

PSYCHOSOCIAL

Shift work, workload, dealing with the public, harassment, discrimination, threat of danger, constant low-level noise, stress, violence, etc.

RISK ASSESSMENT

Risk can be presented in variety of ways to communicate the results of analysis to make decision on risk control.

For risk analysis that uses likelihood and severity in qualitative method, presenting result in a risk matrix is a very effective way of communicating the distribution of the risk throughout a plant and area in a workplace.

Risk can be calculated using the following formula:

L (Likelihood) x S (Severity) = Relative Risk (RR)

LIKELIHOOD OF OCCURANCE

This value is based on the likelihood of an event occurring. You may ask the question "How many times has this event happened in the past?" Assessing likelihood is based worker experience, analysis or measurement.

EXAMPLE	RATING
The most likely result of the hazard / event being realized	5
Has a good chance of occurring and is not unusual	4
Might be occur at sometime in future	3
Has not been known to occur after many years	2
Is practically impossible and has never occurred	1
	The most likely result of the hazard / event being realized Has a good chance of occurring and is not unusual Might be occur at sometime in future Has not been known to occur after many years

Table A

SEVERITY OF HAZARD

Severity can be divided into five categories. Severity are based upon an increasing level of severity to an individual's health, the environment, or to property. Table B indicates severity by using the following table:

SEVERITY (S)	EXAMPLE	RATING
Catastrophic	Numerous fatalities, irrecoverable property damage and productivity	5
Fatal	Approximately one single fatality major property damage if hazard is realized	4
Serious	Non-fatal injury, permanent disability	3
Minor	Disabling but not permanent injury	2
Negligible	Minor abrasions, bruises, cuts, first aid type injury	1

Table B

RISK MATRIX TABLE

	Severity (S)				
Likelihood (L)	1	2	3	4	5
5	5	10	15	20	25
4	4	8	12	16	20
3	3	6	9	12	15
2	2	4	6	8	10
1	1	2	3	4	5

Table C








RISK PRIORITY TABLE

RISK	DESCRIPTION	ACTION
15 - 25	HIGH	A HIGH risk requires immediate action to control the hazard as detailed in the hierarchy of control. Actions taken must be documented on the risk assessment form including date for completion.
5 - 12	MEDIUM	A MEDIUM risk requires a planned approach to controlling the hazard and applies temporary measure if required. Actions taken must be documented on the risk assessment form including date for completion.
1 - 4	LOW	A risk identified as LOW may be considered as acceptable and further reduction may not be necessary. However, if the risk can be resolved quickly and efficiently, control measures should be implemented and recorded.

Table D



8K = LIKELIHOOD X SEVERITY 6-12 MEDIUM

CONTROL

Control is the elimination or inactivation of a hazard in a manner such that the hazard does not pose a risk to workers who have to enter into an area or work on equipment in the course of scheduled work.



Hazard Identification, Risk Assessment & Risk Control (HIRARC)


Safety

freedom from unacceptable risk of harm




Tolerable Risk

Risk that has been reduce to a level that can be accepted by the organisation having regard to its legal obligations and its own OH&S policy.



1. ELIMINATION

- Remove hazard from workplace
- Get rid the hazardous job, tools, process, equipment, machines or substances



2. SUBSTITUTION


- · Doing the same work in less hazardous way.
- Replace of substances with a less hazardous substances.






3. ISOLATION

- Keep hazard away from workers
- · Install guard, barrier
- Lockout system
- · Safe clearance



4. ENGINEERING CONTROL

- Modification
- Redesign
- · Local exhaust ventilation





REDESIGN

Jobs and processes can be reworked to make them safer. For example, containers can be made easier to hold and lift.

ISOLATION

If a hazard cannot be eliminated or replaced, it can some times be isolated, contained or otherwise kept away from workers. For example, an insulated and airconditioned control room can protect operators from a toxic chemical.

AUTOMATION

Dangerous processes can be automated or mechanized. For example, computer-controlled robots can handle spot welding operations in car plants. Care must be taken to protect workers from robotic hazards.

ENGINEERING CONTROL

BARRIERS

A hazard can be blocked before it reaches workers. For example, special curtains can prevent eye injuries from welding arc radiation. Proper equipment guarding will protect workers from contacting moving parts.

ABSORPTION

Baffles can block or absorb noise. Lockout systems can isolate energy sources during repair and maintenance.
Usually, the further a control keeps a hazard away from workers, the more effective it is.

DILUTION

Baffles can block or absorb noise. Lockout systems can isolate energy sources during repair and maintenance. Usually, the further a control keeps a hazard away from workers, the more effective it is.

5. ADMINISTRATIVE CONTROL

- Implement policies, procedures and training.
- Signages
- Supervision
- Inspection









ADMINISTRATIVE CONTROL

Safe work procedures

Workers can be required to use standardized safety practices. The employer is expected to ensure that workers follow these practices. Work procedures must be periodically reviewed with workers and updated.



Initial training on safe work procedures and refresher training should be offered. Appropriate supervision to assist workers in identifying possible hazards and evaluating work procedures.

Job rotations

Reduce the time that workers are exposed to a hazard. For example, workers can be rotated through jobs requiring repetitive tendon and muscle movements to prevent cumulative trauma injuries. Noisy processes can be scheduled when no one is in the workplace.

Housekee<mark>ping, r</mark>epair and mainten<mark>ance p</mark>rograms

Housekeeping includes cleaning, waste disposal and spill cleanup. Tools, equipment and machinery are less likely to cause injury if they are kept clean and well maintained.

Hygiene practices can reduce the risk of toxic materials being absorbed by workers or carried home to their families.

Hvaiene

6. PPE

Safety helmet, mask, safety shoe, apron, rubber mat, gloves, ear muff etc.







PERSONAL PROTECTION EQUIPMENT

Personal protective equipment (PPE) and clothing is used when other controls measures are not feasible and where additional protection is needed. Workers must be trained to use and maintain equipment properly. The employer and workers must understand the limitations of the personal protective equipment. The employer is expected to require workers to use their equipment whenever it is needed. Care must be taken to ensure that equipment is working properly. Otherwise, PPE may endanger a workers health by providing an illusion of protection.

PPE is acceptable only in the following situation:

According to OSHA, PPE is acceptable as a control method in the following situations:



When engineering controls are not feasible or do not completely eliminate the hazard



While engineering controls are being developed



When administrative controls and safe work practices do not provide sufficient protection



During emergencies when engineering controls may not be available or feasible for use

Hierarchy of Controls

Most Effective

- Elimination of hazard—remove sharps and needles and eliminate all unnecessary injections. Jet injectors may substitute for syringes and needles. Other examples include the elimination of unnecessary sharps like towel clips, and using needleless IV systems.
- Engineering controls—examples include needles that retract, sheathe or blunt immediately after use.
- Administrative controls—policies aimed to limit exposure to the hazard. Examples include allocation of resources demonstrating a commitment to health care worker safety, a needlestick prevention committee, an exposure control plan, removing all unsafe devices, and consistent training on the use of safe devices.
- Work practice controls—examples include no re-capping, placing sharps containers at eye-level and at arms reach, emptying sharps containers before they're full, and establishing the means for safe handling and disposing of sharps devices before beginning a procedure.
- Personal Protective Equipment (PPE)—barriers and filters between the worker and the hazard. Examples include eye goggles, gloves, masks, and gowns.

Least Effective



Hierarchy of Infection Control Measures

Medic Footprints

Ways Doctors & HCW can reduce their COVID-19 exposure

Most effective

Remove exposure

Avoid face 2 face consultations, use tele-consultations, work from home (with no patients!)



Substitute exposure

Administer aerosolised medicine with spacers instead of nebulisers

Isolate yourself

Place physical barriers
Avoid physical exam of
suspected/known cases

Change the way you work

Disinfect re-use equipment inc. computers, reduce face to face time, rotate b/w exposed & non-exposed roles


Least effective

Use PPE

Gloves, masks, gowns, scrubs

Source: CDC

https://www.cdc.gov/niosh/topics/hierarchy/default.html



RISK CONTROL				
Recommended Control Measures	PIC (Due Date / Status)			
Ensure availability of gloves and other protective equipment and cleansing agents	Mr. A (30/12/2012)			
NIL				
Train staff on proper lifting techniques	Mr. B (30/12/2012)			
Train staff on diffusing situations and intervention procedures	Mr. C (30/12/2012)			
	Recommended Control Measures Ensure availability of gloves and other protective equipment and cleansing agents NIL Train staff on proper lifting techniques Train staff on diffusing situations and intervention			

Kesimpulan

- . Pengenalpastian hazard, penilaian risiko, kawalan dan semakan semula bukanlah suatu tugas yang dibuat sekali sahaja dan dilupakan tetapi ianya suatu aktiviti yang berterusan.
- . HIRARC hendaklah didokumentasikan walaupun seringkas mana sekalipun.
- . HIRARC hendaklah jalankan dengan penilaian teliti ke atas kebarangkalian dan juga kesan akibat manakala langkah kawalan yang dicadangkan hendaklah menepati hirarki kawalan



ELIKELIHOOD X SEVERITY 16 - 25 : HIGH RISK 5-12 MEDIUM 1 - 4 : LOW RISK

JOB TITLE: Working in Clinic

HAZARD IDENTIFICATION No Activities / R/NR Hazard Consequences **Equipment/Faculties** R 1 handling patients, Infectious Diseases Hepatitis B, Hepatitis C contaminated objects, and Human body secretions, tissue Immunodeficiency or fluids Virus (HIV) can be spread Using X-ray machine Cancer Exposure to radioactive 2 R and radiation Fatality Heavy lifting and frequent Back injuries Handling patients & 3 moving objects R bending or twisting when moving objects or patients Health care workers are at Workplace violence can Dealing with angry and 4 stressed patients and risk from violence result in loss of sleep, R their families. fear or depression, post traumatic stress disorder

^{*}R-Routine, NR - Non Routine

RISK ASSESSMENT					
Current Risk Control	Likelihood	Severity	Risk Level		
Wash hands frequently (proper hand washing is the best way to prevent communicable diseases)	3	3	9 (M)		
Competency & Proper PPE to be worn Safe work distance, allowable exposure limit	2	2	4 (L)		
Use proper lifting technique	3	3	9 (M)		
Follow policies and intervention guidelines	3	3	9 (M)		

	LIKELIHOOD	SEVERITY		
Most Likely (5)	The most likely result of the hazard / event being realized	Catastrophic (5)	Numerous fatalities	
Possible (4)	Has a good change of occurring and is not unusual (1-5 years)	Fatal (4)	Approximately one single fatality	
Conceivable (3)	Might be occur at sometime in future (5-10 years)	Serious (3)	Non-fatal injury, permanent disability or > 4 days MC	
Remote (2)	Has not been known to occur after many years (10 yrs)	Minor (2)	Disabling but not permanent injury or 1-4 days MC	
Inconceivable (1)	Is practically impossible and has never occurred	Negligible (1)	Minor abrasions, bruises, cut, first aid type injury	

RISK = LIKELIHOOD X SEVERITY

15 - 25 : HIGH RISK

5-12 : MEDIUM RISK 1 -4: LOW RISK

RISK CONTROL					
Type of Control	Recommended Control Measures	PIC (Due Date / Status)			
Administrative	Ensure availability of gloves and other protective equipment and cleansing agents	Mr. A (30/12/2012)			
NIL	NIL				
Administrative	Train staff on proper lifting techniques	Mr. B (30/12/2012)			
Administrative	Train staff on diffusing situations and intervention procedures	Mr. C (30/12/2012)			

